

TomTom Golfer Reference Guide

1.0.8



Contents

Welcome	4
New features	5
New in this release	5
Getting started	6
Your watch	8
About your watch	8
Cleaning your watch.....	8
Using the desk dock	9
Watch status	9
Performing a Reset	10
Playing a round of golf	12
Quick Start: Playing your first hole	12
Quick Start: Button checklist	12
Choosing a course	14
Updating golf course information	14
Pausing, stopping and continuing a round.....	15
Doglegs	16
About doglegs	16
Understanding doglegs on your watch	16
Laying up	18
About laying up	18
Laying up using your watch	18
Layup and green views.....	19
Approaching the green	20
About greens.....	20
Approaching the green using your watch	20
Layup and green views.....	21
Hazards	23
About hazards	23
Understanding hazards on your watch	23
Scoring	26
About scoring	26
Scoring using your watch	26
Viewing previous scores	27

Settings	29
About settings	29
Clock	29
Phone	29
Airplane mode	31
Options	31
Profile.....	32
TomTom MySports account	33
TomTom MySports Connect	34
TomTom MySports mobile app	35
Glossary of Terms	36
Addendum	38
Copyright notices	41

Welcome

This Reference Guide explains everything you need to know about your new TomTom Golfer watch.

If you want a quick read of the essentials, we recommend that you read the [Getting started](#). This covers downloading TomTom MySports Connect and using the desk dock.

After that, if you have a smartphone, you will probably want to download the TomTom MySports app for free from your usual app store or by going to tomtom.com/app.

Important: Before using the MySports app on your smartphone, you need to link your watch to your MySports account using a computer. This needs to be done only once.

For information about what you see on the watch and how to use it, here are some good starting points:

- [New features](#)
- [About your watch](#)
- [Quick Start: Playing your first hole](#)
- [Settings](#)

Tip: There are also frequently asked questions (FAQs) at tomtom.com/support. Select your product model from the list or enter a search term.

We hope you enjoy reading about and, most importantly, playing golf with your new TomTom Golfer!

New features

New in this release

Note: To get the most out of your watch we recommend that you reinstall all courses globally. Reinstalling all courses can take up to two hours.

Simplified hazards view

The hazards view has been simplified to provide at-a-glance distances.

To learn more, go to [Understanding hazards on your watch](#).

Doglegs and corner distances

Doglegs are now included on the range screen. Dogleg direction and corner distance are now included in the hazards view.

To learn more, go to [Quick Start: Playing your first hole](#) and [Understanding doglegs on your watch](#).

Distance to dogleg

Distance to dogleg in the hazards view is now measured along the course center line.

To learn more, go to [Understanding doglegs on your watch](#).

Advance to next hole

Your watch now advances to the next hole more accurately.

To learn more, go to [Options](#).

Language support has been added for Traditional and Simplified Chinese.


Minor bug fixes and performance improvements have been made.

Getting started

Before you start playing golf, it's a good idea to charge your watch, download any software updates, and download QuickGPSFix.

Note: QuickGPSFix helps your watch get a GPS fix and find your location quickly.

1. Download [TomTom MySports Connect](https://www.tomtom.com/getstarted/sports) from [tomtom.com/getstarted/sports](https://www.tomtom.com/getstarted/sports) and install it on your computer. TomTom MySports Connect is available for free.
2. Place your watch in the [desk dock](#) and connect the dock to your computer. Follow the instructions that TomTom MySports Connect gives you.



After your watch is charged, you can [play your first hole](#).

Tip: Your watch is fully charged when the battery animation stops moving and shows a full battery.

You should connect your watch to your computer regularly to charge it, update golf course information, download software updates, and download QuickGPSFix information.

Important: You can also use any USB wall charger to charge your TomTom Golfer. Place your watch in the desk dock and then connect the USB connector from the desk dock to your USB wall charger.

Battery life

When the battery is fully charged, your watch can be used for up to 10 hours of playing golf. The battery is used more quickly if you frequently use the [backlight](#) on your watch.

Tip: Your watch shows a low battery symbol if there is not enough charge for a complete round of golf (4 hours). A low battery symbol with a line through it means that you need to charge your watch immediately.

TomTom MySports app

Important: Before using the MySports app on your smartphone, you need to link your watch to your MySports account using a computer. This needs to be done only once.

You can download the TomTom MySports app for free from your usual app store or by going to [tomtom.com/app](https://www.tomtom.com/app).

To learn more, go to [TomTom MySports mobile app](#) in this guide.

Pairing your watch with your phone

To learn more, go to [Phone](#) in this guide.

Your watch

About your watch

When you use your watch, you start from the clock screen. This screen shows the [time and date](#). The hour number is shown slightly dimmed and the minutes are shown brighter so you can see the precise time more clearly.

Use the button to move Up, Down, Left or Right to other screens on your watch.



1. Left - opens the [Status](#) screen.
2. Down - opens the [Settings](#) menu.
3. Right - opens the [Golf course](#) menu.
4. Up - opens the [Scorecard history](#) screen.
5. GPS receiver. While wearing the watch, the GPS receiver should face upwards.
6. Touch this area of the screen to turn on the backlight.

The clock screen shows the time and date. You can choose to show the time in 12 hour or 24 hour format by moving down to open the [Settings](#) menu, then selecting **Clock**.

Using your watch

Move Up or Down to select items in a menu.

Move Right to select an item and open the menu for that item.

Move Left to exit a menu.

To select an option in a menu, make sure it is highlighted when you leave the menu. Your watch remembers the option you highlighted.

If a menu option can be turned on and off, move Right to change the setting.

Cleaning your watch


It is recommended that you clean your watch once a week if you use it frequently.

- Wipe the watch with a damp cloth as needed. Use mild soap to remove oil or dirt.
- Do not expose your watch to strong chemicals such as gasoline, cleaning solvents, acetone, alcohol, or insect repellents. Chemicals can damage the watch's seal, case, and finish.

Using the desk dock

You can use the desk dock when your watch is in the wrist strap or you can remove your watch from the wrist strap first.

To remove the watch from the wrist strap, hold the watch in one hand and lift the strap upwards, away from the watch. The wrist strap pops off the front of the watch.



To place your watch in the desk dock, slide the watch into the dock, following the curve of the back of the watch.

To remove your watch from the desk dock, push underneath the screen of the watch. The watch will slide out, following the curve of the back of the watch. Do not lift the watch from the top, as this can damage the desk dock.

Important: You can also use any USB wall charger to charge your TomTom Golfer. Place your watch in the desk dock and then connect the USB connector from the desk dock to your USB wall charger.

Watch status

From the clock screen, move Left to open the status screen.

The status screen shows the following information:

- **Battery** - the battery power remaining on your watch.

To charge the battery, place the watch in the desk dock and connect the dock to your computer.

- **QuickGPS** - the status of the QuickGPSFix information on your watch.

QuickGPSFix helps your watch find your precise location quickly so that you can start your round of golf. To update the QuickGPSFix information on your watch, connect your watch to your computer. TomTom MySports Connect automatically updates QuickGPSFix on your watch. QuickGPSFix information is valid for three days after you download it.

These symbols are used to show the status of QuickGPSFix:



QuickGPSFix on your watch is up to date.



or



QuickGPSFix on your watch is out of date. If the QuickGPSFix information on your watch is out of date, your watch still works as usual. It may, however, take longer to get a GPS fix when you want to [play a round of golf](#).

If you see this icon, you are using a very old version of the software and should update your watch as soon as possible.

- **Version** - the software version number and serial number of your watch. You may need this information if you contact Customer Support. Every time you connect your watch to your computer, TomTom MySports Connect checks if a software update is available for your watch.

Performing a Reset

Soft reset

A soft reset is performed each time you disconnect your watch from a wall charger or computer.

To perform a soft reset on your watch, follow these steps:

1. Connect your watch to a wall charger or computer.
Wait until your watch shows a battery symbol.
If you are using a computer, wait until MySports Connect finishes updating your watch.
2. Disconnect your watch from the wall charger or computer.
The software on your watch restarts. This performs a soft reset on your watch.

Recovery mode

Before you perform a factory reset on your watch you should try updating the watch software using the recovery mode. The recovery mode allows you to reinstall the software on your watch without deleting any personal data and settings.

To perform a reset on your watch using the recovery mode, follow these steps:

1. Connect your watch to your computer and wait until MySports Connect finishes updating your watch.
2. On your watch, move Down but keep the button pressed.*
3. Disconnect the USB cable from your computer.*
4. Keep pressing the button until your watch shows a watch connected with a computer and tomtom.com/reset.
5. Release the button and connect the USB cable to your computer.
6. Click **Update** in MySports Connect.

* If the USB port on your computer is not easily accessible, connect the dock to the computer without the watch. Then move down from the clock screen while you slide the watch into the dock.

Factory reset

Important: A factory reset removes all golf courses and settings from your watch and then reinstalls the software. To reinstall golf courses after a reset, connect your watch to your computer and follow the instructions to open a MySports account. If you don't want to perform a factory reset now, select Cancel and then select Update instead.

You should only use a factory reset as a last resort to restore your watch or if you really want to remove all your golf courses and settings.

A factory reset reinstalls the software on your watch and removes the following:

- Your golf courses.
- Your scorecard history.
- Your settings on the watch.

Important: When you perform a factory reset, do not disconnect your watch before MySports Connect has finished restoring your watch. Installing the software on your watch takes several minutes. You then need to set up your watch in MySports Connect before you can install the golf courses again. Check any messages shown in MySports Connect and on your watch before you disconnect your watch.

To perform a factory reset on your watch, follow these steps:

1. Connect your watch to your computer and wait until MySports Connect finishes updating your watch.

2. Expand **SETTINGS** in MySports Connect.
3. Click **FACTORY RESET** at the bottom of MySports Connect.
MySports Connect downloads the latest version of the software for your watch.
4. Keep your watch connected when the window for MySports Connect closes.
MySports Connect installs the software on your watch.
5. Keep your watch connected when the window for MySports Connect opens again.
6. Follow the instructions in MySports Connect to setup your watch.

Playing a round of golf

Quick Start: Playing your first hole

To play your first hole, do the following:

1. From the clock screen, move Right.
Your watch shows **Please wait**. When a GPS fix is found, you see a list of nearby golf courses.
2. Move Up or Down to select a course, then move Right to start a round.
3. The first hole is shown, and you see the following information on the range screen on your watch:
 - Dogleg, if present, and dogleg direction.
 - Hole number (next to the flag symbol).
 - Par for the hole.
 - Distance from your position to the back, center and front of the green.

Note: Distance to the pin is not shown because pin placement may vary from day to day.

Tip: Move Right to see more information about the hole.



4. Take any practice strokes that you need. Play your first stroke and then walk to the location of your golf ball.
The remaining distance to the hole is shown.
5. Play the remainder of the strokes for this hole until you hole out.
6. Move Right twice to enter the score for your first hole.
7. Walk to the second hole. Your watch automatically advances, or you can move Up or Down from the range screen to manually move to the second hole.

Quick Start: Button checklist

To help you get started, here is a list of what the button moves do in each screen:

Name of screen	Button	Action
Clock screen	Move Left	Go to the Watch Status screen.
	Move Up	Go to Scorecard history screen.
	Move Down	Go to the Settings screen.
	Move Right	Please wait while a GPS fix is obtained. When a fix is obtained, go to Golf Course menu.
	Move Right after stopping a round	Go to Resume scorecard screen.
Please wait screen	Move Left	Back to the Clock screen.
	Move Down	Go to the Recent Courses screen.
	Move Right	Nothing happens.
	Move Up	Nothing happens.
Golf course menu	Move Up	Browse up through the list of courses.
	Move Down	Browse down through the list of courses.
	Move Right	Start your round on your selected course.
Range screen	Move Up	Go to the next hole.
	Move Down	Go to the previous hole.
	Move Right	Go to the Hazards, Layup or Green view screen, depending on which are applicable for the current hole. Green view is always present Move Right again to go to the Scorecard screen.
	Move Left	Pauses your round.
	Move Right	Continue your round after a pause.
Pause screen	Move Left	Stops your round and goes back to the Clock screen.
	Move Right	Continue your round after a pause.
	Move Up	Keep moving Up to cycle through the Hazards, Layup or Green view screen, depending on which are applicable for the current hole. Green view is always present.
	Move Down	Keep moving Down to cycle through the Hazards, Layup or Green view screen, depending on which are applicable for the current hole. Green view is always present.
	Move Left	Go back to the Range screen.
Scorecard screen	Move Right	Go to the Scorecard screen.
	Move Left	Go to the Hazards, Layup or Green view screen, depending on which are applicable for the current

		hole. Green view is always present.
	Move Right	Nothing happens.
	Move Up	Add strokes to your score for that hole.
	Move Down	Remove strokes from your score for that hole.

Choosing a course

Tip: When your watch shows **Please wait** while waiting for a QuickGPSFix, you can move Down to browse recent courses. The watch vibrates when a fix is found.

Move Up or Down to in the golf course menu to choose a golf course.



Move Right when you are ready to start playing.

Move Left to go back to the clock screen.

Note: To find out if your golf course is available on the watch, go to tomtom.com/course-coverage. The page is available in English.

Updating golf course information

One-off update to start receiving incremental course updates

To allow your watch to receive incremental updates, we recommend that you reinstall all courses globally.

Note: Reinstalling all courses can take up to two hours.

To update your Golfer, follow these steps:

1. Connect your watch to your computer.
2. MySports Connect downloads and installs the latest changes to your recently played golf courses.
3. In MySports Connect, click **Update**.
4. MySports Connect downloads and installs the latest software version.

Note: Only software version 1.0.5 or higher supports incremental course updates.

5. Select the **GOLF COURSES** tab in MySports Connect and click **REINSTALL COURSES**.
6. MySports Connect downloads and installs all courses globally.

Updating course information thereafter

You can update the golf courses on your TomTom Golfer in two ways:

1. [TomTom MySports mobile app](#)

If you have a compatible phone, you can use the TomTom MySports mobile app to update all recent golf courses and those within a range of 3 kilometers (1.8 miles).

2. [TomTom MySports Connect](#)

Each time you connect your watch to your computer, MySports Connect downloads and installs the latest changes to your recently played golf courses.

If you need to update all golf courses globally, for example when you plan to travel, expand **SETTINGS** in MySports Connect. Select the **GOLF COURSES** tab and click **GLOBAL UPDATE**.

Note that a global update will take about an hour to complete.

Pausing, stopping and continuing a round

Pausing and restarting a round of golf

During a round of golf, move Left to stop the clock and pause your round.

To resume your round again, move Right.

Stopping a round of golf

To stop the round, move Left to pause and then move Left again to return to the Clock screen.

Continuing a round of golf

To continue a round of golf, do the following:

1. From the Clock screen, move Right and choose the course you were playing previously.
2. Move Right to go to the Range screen.
You are asked if you wish to resume your scorecard.
3. Move Right to choose "yes" or move Left to select "no."

Note: You can resume a scorecard for up to 24 hours after pausing a round and returning to the Clock screen. The scorecard is still saved in your Score history if you select "no."

Doglegs

About doglegs

Some holes are deliberately designed with no direct line-of-sight from the tee to the green.

A hole may bend either to the left or to the right and this bend is called a "dogleg," in reference to the similarity to a dog's ankle.

There are three types of dogleg:

- A "dogleg left" - the hole bends to the left as you look toward the green from the tee.
- A "dogleg right" - the hole bends to the right as you look toward the green from the tee.
- A "double dogleg" - there are two bends, for example in an "S" shape, as you look toward the green from the tee.

See also: [Understanding doglegs on your watch](#)

Understanding doglegs on your watch

Your TomTom Golfer can show whether any doglegs are present on a hole.

On your watch, doglegs are shown as an arrow icon on the range screen. The direction the arrow points shows you whether the dogleg bends to left or to the right.



You may choose to hit over a dogleg or to [lay up](#) instead.

See: [About doglegs](#)

Position of doglegs on the fairway

Your TomTom Golfer shows the position of doglegs relative to their position on the actual course.

For example, the watch below is showing a dogleg right at 230 yards/meters from your current position.



The distance to the start of the dogleg is measured along the course center line.

Laying up

About laying up

A layup shot is made from the fairway after the drive, but due to the presence of a hazard, you have to deliberately make the shot shorter than usual or more accurate. This called laying up.

Most often, you lay up to avoid hitting the ball into a hazard on the fairway, or to put the ball in a more favorable position on the fairway for the next shot.


See also: [Laying up using your watch](#)

Laying up using your watch

The layup screen during play (see below) shows the layup markers on the left-hand side of the watch screen and your current distance from that marker on the right-hand side of the watch screen.

So as you look toward the pin, you can see how far away you currently are from the 200, 150 and 100 yard/meter markers.

For example, in the image below, the golfer is 236 yards/meters from the 200 yard/meter layup marker.



As you walk the hole toward the pin, your current distance from the first L200 marker on the right-hand side of the watch screen decreases.

When you reach a layup marker, the layup marker disappears from the screen.

The default distances for the layup markers are 100, 150, 200.

Note: Keep moving Up to cycle through the Hazards, Layup or Green view screen, depending on which are applicable for the current hole. Green view is always present.

Tip: If poor or a loss of signal occurs, the range values gray and display the last values that were deemed to be good or accurate.

See also: [Layup and green views](#)

Layup and green views

As you approach the [green](#), move Up or Down to swap between the layup screen and the green view as shown below.



Once you have passed the last layup marker, the watch automatically shows only the view of the green.

See also: [Approaching the green using your watch](#)

Approaching the green

About greens

A green, or putting green, is an area of closely trimmed grass surrounding the hole or pin. Holing out or getting the ball into the hole with the minimum number of strokes possible is the main aim of playing golf.

The green allows players to putt or make precision strokes using a putter. A putter has very low loft or angle on the face of the club so that the ball rolls smoothly along the ground, and hopefully into the hole.

Usually the green is flatter than other areas of the course, though gentle slopes and undulations can be found on some courses. Sand or water hazards are often placed adjacent to the green, which makes the approach to the pin more challenging and can require the golfer to [lay up](#).

The location of the hole changes from day to day to promote even wear of the turf on the green.

The grass of the green is cut very short so that a ball can roll for a long distance. The green is typically surrounded by slightly higher grass known as the fringe, and then by the fairway and/or rough. The fringe slows the ball and stops it rolling along the green from an approach shot or putt, preventing the ball from leaving the green.

Though it is possible to putt on the fringe, the longer grass interferes with the path of the ball. Hence players often choose to use a lofted club such as an iron to make a chip shot, where the ball carries in the air for a few yards and then rolls along the green like a normal putt.


See also: [Approaching the green using your watch](#)

Approaching the green using your watch

As seen from the example below, the shape of the green on your watch mirrors the shape of the actual green that you are approaching.

Any surrounding hazards are shown as patterns. Water is shown using a wave pattern and bunkers as a dotted pattern. If a water and sand hazard are in the same area surrounding the green, water takes priority and that pattern is shown over the sand pattern. For more information on hazards, see [About hazards](#).

The pin location is shown and reflects the middle value on the range screen.



See also: [Layup and green views](#)

Layup and green views

As you approach the [green](#), move Up or Down to swap between the layup screen and the green view as shown below.



Once you have passed the last layup marker, the watch automatically shows only the view of the green.

See also: [Approaching the green using your watch](#)

Hazards

About hazards

A hazard is an area of a golf course which provides a difficult obstacle for the golfer to negotiate. A course may include water hazards such as lakes and rivers, man-made hazards such as bunkers, and natural hazards such as trees or thick vegetation.

Many recreational golfers use the term "hazard" to mean anything on a golf course that is hazardous to one's score such as thick rough or a tall tree in the middle of a fairway.

A ball is considered to be in a hazard when any part of the ball touches that hazard. Special rules apply to playing balls that have landed in a hazard. For example, a player may not touch the ground with his club before playing a ball, not even for a practice swing. A ball in any hazard may be played as it lies without penalty. If it cannot be played from the hazard, the ball may be hit from another location, generally with a penalty of one stroke.

Bunkers

A bunker is a steep-sided hole or shallow pit near the green or fairway that is usually filled with sand. It can be more difficult to play a ball from sand than from grass and bunkers sometimes have a raised lip which makes it difficult to hit the ball out of the bunker.

To hit the ball out of a bunker, you usually need to use a very lofted club called a "sand wedge". Specific rules of golf govern play from a bunker. Also, after playing out of a bunker, the player or their caddy must rake smooth the area of the sand disturbed during play.

There are three types of bunkers used when designing a course and all are designed to impede the golfer's progress toward the green. Bunkers in the middle or sides of the fairway can catch inaccurate tee shots on par 4 and par 5 holes. Bunkers near and around the green can collect inaccurate approach shots on long holes and tee shots on par 3 holes. On links or coastal courses, very large natural sandy areas are not considered to be hazards according to the rules of golf, and the rules are different for these areas from other bunkers.

Water hazards

Water hazards are usually natural obstacles that add difficulty to a golf course, though on brand new courses they can of course be man-made. A water hazard may typically be a stream or pond, positioned next to the fairway or across a fairway, forcing the player to hit the ball over the water hazard.

Tip: Water hazards don't have to actually have water in them to count as hazards.

See also: [Understanding hazards on your watch](#)

Understanding hazards on your watch

Your TomTom Golfer can show you nearby water hazards or bunkers that are within 300 meters (328 yards).

On your watch, hazards are shown as a water or sand pattern, alongside distance measurements to the hole, such as 293 (back) and 278 (front) as shown below.



Position of hazards on the fairway

Your TomTom Golfer shows the position of hazards relative to their position on the actual course.

For example, the watch below is showing a [bunker](#) approximately 220 yards/meters on the right and a [water hazard](#) 275 yards/meters straight ahead that you will need to hit the ball over - it is approximately 15 yards/meters wide.



If there are no hazards on a hole or you have passed them already, you see a check mark in the middle of the Hazards screen.

Note: When there is no information available about hazards on a hole, you see a message saying **No info.**

Scoring

About scoring

Your TomTom Golfer can be used for normal stroke play, also known as medal play. This involves counting the total number of strokes taken on each hole during a round, or series of rounds. The winner is the player who has taken the fewest number of strokes over the course of the round, or rounds.

The par value for a golf course is the predetermined number of strokes that a scratch or zero handicap golfer needs to play a hole, a round (the sum of the pars of the played holes), or a tournament (the sum of the pars of each round).

A golfer's score is compared with the par score. If a course has a par of 72 and a golfer takes 76 strokes to complete the course, the reported score is +4, or four over par, taking four shots more than par to complete the course. If a golfer takes 69 strokes, their reported score is -3, or three under par.

Tip: It is mainly the length of the hole from the tee position to the pin that sets the par value for a hole. Other things that affect the par chosen for each hole include the terrain and obstacles, such as trees, hazards, hills, or buildings, any of which may mean that the golfer takes more or fewer shots. Most eighteen hole courses that were not designed for championships have a par close to seventy-two.

See also: [Scoring using your watch](#)

Scoring using your watch

After playing a hole, move Right until you see the scorecard screen. The scorecard is used for recording your score for each hole, and it also shows you your total score so far for the round.



1. Your score relative to par for the round.
"E" means even par for the hole. A plus sign (+) means over par, and a minus sign (-) below par.
2. The identifying number of the hole, for example, here the golfer is on the first hole.
3. The par for the hole. For example, the first hole shown above is a par 5.

4. The total number of strokes taken so far for a round. In this example, the golfer has played one hole and taken 5 strokes so the total for the round so far is also 5 strokes.
5. The number of strokes for the hole just played.

Enter the score for a hole by moving Up and Down until the number of strokes that you played for that hole are shown.

Note: If you hit a ball [out of bounds](#) or onto an adjoining hole by mistake, just record the extra strokes on your watch as part of the total for that hole after you finished playing it.

See also: [Viewing previous scores](#)

Viewing previous scores

1. Move Up from the clock screen to see scores from your previous rounds.



You see the dates of your recent rounds along with the overall score for the round, for example as shown above, 3 under, 2 under or even par.

2. Move Up and Down to choose a previous round to look at in more detail, then move Right. You see the name of the course you played.

3. Move Right to see the par and total score for the round, split into the front 9 holes and back 9 holes, as shown below.



4. Move Right to see the score for each hole of that previous round.
5. Move Left to go back to the name of the course.

Settings

About settings

From the clock screen, move down to open the **Settings** menu. These settings determine the overall behavior of your watch.

The following settings are available for your watch:

- [Clock](#)
- [Phone](#)
- [Airplane mode](#)
- [Options](#)
- [Profile](#)

Clock

From the clock screen, move down to open the **Settings** menu, then select **Clock** and move Right to open the **Clock** menu.

Alarm

Select **Alarm** to turn the alarm on and off and to set the alarm time.

When the alarm goes off, move Left to stop it or move Right to snooze. If you snooze the alarm, it goes off again in 9 minutes.

Time

Select **Time** to set the time on your watch. The time is either set using the 12- or 24-hour clock, depending on the setting for **24HR**.

Date

Select **Date** to set the date on your watch.

24HR

Select **24HR** to switch between using the 12-hour clock and the 24-hour clock to display and set the time. Move Right to switch between **ON** and **OFF** for this setting.

Phone

For information as to why you should want to pair your watch with your phone or mobile device, see TomTom MySports app.

To pair your watch with a phone or mobile device, do the following:

1. Make sure that your phone or mobile device is close by.
2. On your phone, make sure that Bluetooth is enabled.
3. From the clock screen on your watch, move down to open the **Settings** screen, then select **Phone** and move right.
4. Move right to start pairing.

5. On your phone, start the MySports Connect app and tap to connect.



6. When the name of your watch appears, tap on it.
7. On your phone, enter the pin number shown on the watch, then tap **Pair**.
Your watch is now paired with your phone or mobile device.
When pairing has been completed, you see a "Connected" message on your watch.



As long as you have the mobile app active or running in the background on your phone or mobile device, the watch automatically tries to connect when it has a new activity to upload or when the QuickGPSFix data is out of date.

If you open the MySports app on your phone and it is trying to connect to your watch, you may need to wake up your watch by moving away from the clock screen. Move down, left or right from the clock screen.

Synchronizing course information

You can automatically synchronize golf course information with your TomTom MySports account by using this setting.

From the clock screen on your watch, move down to open the **Settings** screen, then select **Phone** and move right.

Select **Sync**. If automatic uploading is currently switched **OFF**, move up or down to switch automatic uploading on.

Airplane mode

From the clock screen on your watch, move Down to open the **Settings** screen, select **Airplane mode** and then move Right.



Move Up or Down to turn on airplane or flight mode.

When airplane mode or flight mode is turned on, an airplane icon is shown on the clock screen and all Bluetooth low energy (also known as BLE or Bluetooth® Smart) connectivity is disabled.

To turn airplane mode off, move Up or Down again.

Options

From the clock screen, move Down to open the **Settings** menu, then select **Options** and move Right to open the **Options** menu.

Units

Select **Units** to set the distance and weight units used on your watch. You can select any combination of yards or meters, and pounds or kilograms.

Click

Select **Click** to set what your watch does as you move through menus. Your watch can do the following:

- Make a clicking sound.
- Vibrate/buzz for short time.

You can turn both on or off, or turn only one on.

Profile

From the clock screen on your watch, move down to open the **Settings** menu, then select **Profile** and move right to open the **Profile** menu.

Select the following options to set your data in each case:

- **Language**
- **Weight**
- **Height**
- **Age**
- **Sex**

Gender is used by the TomTom Golfer when playing a hole that may have different par values for men and women. For example, a hole could be a par 5 for women and a par 4 for men.

Language


Select **Language** to set the language used for menus and messages on your watch.

TomTom MySports account

Your TomTom MySports account is a central storage location for all your sports information.

To create an account, click the button in TomTom MySports Connect, or go directly to the website: mysports.tomtom.com

As you can see from the diagram below, you can manage to your MySports account using either TomTom MySports Connect or the TomTom MySports app.



Important: Before using the MySports app on your smartphone, you need to link your watch to your MySports account using a computer. This needs to be done only once.

TomTom MySports Connect

TomTom MySports Connect does the following:

- Helps you set up your watch.
- Updates the software on your watch when new versions become available.
- Updates golf course information on your watch.
- Transfers any settings you make on TomTom MySports to your watch.
- Updates the QuickGPSFix information on your watch.

Installing TomTom MySports Connect

You can download TomTom MySports Connect for free from here: tomtom.com/getstarted/sports

Once installed, connect your watch to your computer using the [desk dock](#).

TomTom MySports mobile app

The TomTom MySports mobile app does the following:

- Updates golf course information.
- Updates the QuickGPSFix information on your watch.
- Provides an alternative to TomTom MySports Connect for updating QuickGPSFix.

Supported phones and mobile devices

iOS

The TomTom MySports app is compatible with iOS 6 and higher on the following Bluetooth Smart enabled devices:

- iPhone 4S or later.
- iPod touch 5th generation.
- iPad3 or later.
- All iPad mini.

Android

The TomTom MySports app requires Bluetooth Smart (or Bluetooth LE) and Android 4.3 or higher to communicate with your watch. A range of Bluetooth Smart enabled Android devices have been tested to confirm their compatibility with the MySports app. Check your phone's compatibility with the MySports app by visiting the [Google Play Store](#).

Before using the TomTom MySports app

Important: Before using the MySports app on your smartphone, you need to link your watch to your MySports account using a computer. This needs to be done only once.

You can download the TomTom MySports app for free from your usual app store or by going to tomtom.com/app.

Glossary of Terms

B

Bunker

A bunker is a steep-sided hole or shallow pit near the green or fairway that is usually filled with sand. It can be more difficult to play a ball from sand than from grass and bunkers sometimes have a raised lip which makes it difficult to hit the ball out of the bunker.

D

Dogleg

Some holes are deliberately designed with no direct line-of-sight from the tee to the green. A hole may bend either to the left or to the right and this bend is called a "dogleg," in reference to the similarity to a dog's ankle.

G

Green

A green, or putting green, is an area of closely trimmed grass surrounding the hole or pin. Holing out or getting the ball into the hole with the minimum number of strokes possible is the main aim of playing golf.

H

Hazard

A hazard is an area of a golf course which provides a difficult obstacle for the golfer to negotiate. A course may include water hazards such as lakes and rivers, man-made hazards such as bunkers, and natural hazards such as trees or thick vegetation.

Many recreational golfers use the term "hazard" to mean anything on a golf course that is hazardous to one's score such as thick rough or a tall tree in the middle of a fairway.

L

Laying up

A layup shot is made from the fairway after the drive, but due to the presence of a hazard, you have to deliberately make the shot shorter than usual or more accurate. This called laying up.

Most often, you lay up to avoid hitting the ball into a hazard on the fairway, or to put the ball in a more favorable position on the fairway for the next shot.

Layup marker

A layup marker shows you how far away you currently are from the hole. For example, if you see L100, 223, it means that you are 223 yards/meters away from the 100 yard/meter marker.

The L100 marker is 100 yards/meters from the pin.

When you reach a layup marker, the layup marker disappears from the screen.

M

Medal play

Your TomTom Golfer can be used for normal stroke play, also known as medal play. This involves counting the total number of strokes taken on each hole during a round, or series of rounds. The winner is the player who has taken the fewest number of strokes over the course of the round, or rounds.

O

Out of bounds

"Out of bounds" means that the entirety of your ball is laying beyond the boundaries of the golf course or any part of the course. The boundary of the golf course is marked by the committee in charge of the competition or the golf course.

Usually, if your ball is out of bounds, you must play the ball, under penalty of one stroke, as nearly as possible at the spot from which the original ball was last played. However you should refer to the rules for your particular course.

P

Par

The par value for a golf course is the predetermined number of strokes that a scratch or zero handicap golfer needs to play a hole, a round (the sum of the pars of the played holes), or a tournament (the sum of the pars of each round).

A golfer's score is compared with the par score. If a course has a par of 72 and a golfer takes 76 strokes to complete the course, the reported score is +4, or four over par, taking four shots more than par to complete the course. If a golfer takes 69 strokes, their reported score is -3, or three under par.

S

Stroke play

Your TomTom Golfer can be used for normal stroke play, also known as medal play. This involves counting the total number of strokes taken on each hole during a round, or series of rounds. The winner is the player who has taken the fewest number of strokes over the course of the round, or rounds.

W

Water hazard

Water hazards are usually natural obstacles that add difficulty to a golf course, though on brand new courses they can of course be man-made. A water hazard may typically be a stream or pond, positioned next to the fairway or across a fairway, forcing the player to hit the ball over the water hazard.

Addendum

How TomTom uses your information

Information regarding the use of personal information can be found at tomtom.com/privacy.

Battery and Environmental information

This product uses a lithium polymer battery that is not user accessible or user replaceable. Do not open the case or (attempt to) remove the battery. Substances in the product and/or battery may be harmful to the environment or your health if disposed of improperly. The battery contained in the product must be recycled or disposed of properly according to the local laws and regulations and always kept separate from household waste.



WEEE directive

The symbol on the product or its packaging indicates that this product shall not be treated as household waste. In line with EU Directive 2012/19/EU for waste electrical and electronic equipment (WEEE), this electrical product must not be disposed of as unsorted municipal waste. Please dispose of this product by returning it to the point of sale or to your local municipal collection point for recycling. By doing this you will help conserve the environment.



Battery operating temperatures

Operating temperatures: -20°C (-4°F) to 60°C (140°F). Do not expose to temperatures beyond this.

R&TTE directive

Hereby, TomTom declares that TomTom products and accessories are in compliance with the essential requirements and other relevant provisions of EU Directive 1999/5/EC. The declaration of conformity can be found here: tomtom.com/legal.



FCC information for the user



THE DEVICE COMPLIES WITH PART 15 OF THE FCC RULES

Federal Communications Commission (FCC) Statement

This equipment radiates radio frequency energy and if not used properly - that is, in strict accordance with the instructions in this manual - may cause interference to radio communications and television reception.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC ID: S4L-8RG0

IC ID: 5767A-8RG0

FCC RF Radiation Exposure Statement

The transmitters within this device must not be co-located or operating in conjunction with any other antenna or transmitter.

Responsible party in North America

TomTom, Inc., 24 New England Executive Park, Suite 410, Burlington, MA 01803

Tel: 866 486-6866 option 1 (1-866-4-TomTom)

Emissions information for Canada

Operation is subject to the following two conditions:

- This device may not cause interference.
- This device must accept any interference, including interference that may cause undesired operation of the device.

Operation is subject to the condition that this device does not cause harmful interference.

This Class B digital apparatus complies with Canadian ICES-003.

The Country Code Selection feature is disabled for products marketed in the US or Canada.

Equipment is certified to the requirements of RSS-210 for 2.4-GHz.

IMPORTANT NOTE

IC Radiation Exposure Statement:

- This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment.
- This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. To maintain with IC RF exposure compliance requirements, please follow the operation instructions in this manual.

Regulatory Compliance Mark



This product displays the Regulatory Compliance Mark (RCM) to show that it complies with relevant Australian regulations.

Notice for New Zealand

This product displays R-NZ to show it complies with relevant New Zealand regulations.

Customer support contact

Australia: 1300 135 604

New Zealand: 0800 450 973

Model names

8RG0

Copyright notices

© 2015 TomTom. All rights reserved. TomTom and the "two hands" logo are registered trademarks of TomTom N.V. or one of its subsidiaries. Please see tomtom.com/legal for limited warranty and end user license agreements applying to this product.

Linotype, Frutiger and Univers are trademarks of Linotype GmbH registered in the U.S. Patent and Trademark Office and may be registered in certain other jurisdictions.

MHei is a trademark of The Monotype Corporation and may be registered in certain jurisdictions.

AES code

The software included in this product contains AES code under Copyright (c) 1998-2008, Brian Gladman, Worcester, UK. All rights reserved.

Licence terms:

The redistribution and use of this software (with or without changes) is allowed without the payment of fees or royalties provided that the following conditions are adhered to:

Source code distributions include the above copyright notice, this list of conditions and the following disclaimer.

Binary distributions include the above copyright notice, this list of conditions and the following disclaimer in their documentation.

The name of the copyright holder is not used to endorse products built using this software without specific written permission.